



Oxygen safety at patient bedside

- ✓ Check oxygen prescription at least once per shift
- ✓ Provide oxygen via the appropriate device (CPAP / PEEP / NIV devices, nasal specs, masks)
- ✓ Check target oxygen saturation level
- ✓ Monitor and adjust oxygen delivery e.g., max. 15L/min for standard ward flowmeter or high flow as prescribed
- ✓ Check the patient is receiving oxygen flow
- ✓ Read the flowmeter from the centre line (widest part) of the indicator ball
- ✓ Turn off oxygen when:
 - Patient is away from the bed
 - No longer prescribed
- ✓ Report any oxygen leaks and follow local procedure

WARNING:



DO NOT USE inflammable products such as alcohol-based sanitiser or paraffin-based products with patients on oxygen



CHECK AND REMOVE sources of ignition e.g., matches, electronic devices, etc



RESPOND to oxygen alarm by contacting (local point of contact)

and follow local procedure